

## **Setting Instructions:**

- 1) Pull the crown out one click.
- 2) Set the current time by rotating the crown clockwise.
  Reference the 24 hour sub dial to ensure AM/PM hours are observed accordingly (0-12=AM/12-24=PM).
- 3) Push the crown in one click to commence timekeeping.

## **Button Functions:**

Button A: Start / pause timer.

Button B: Reset timer / hands.

## Water Resistance Guidelines

**10 ATM** - short duration and low depth resistance only. Not suitable for extended swimming periods or bathing. Not suitable for diving. **Note:** Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance as water penetration may occur.