

How to Set the Breed Sander (BRD4600's) Watch

- 1) Free the crown protector from its latching mechanism and swing it upwards so the crown is no longer obstructed.
- 2) Pull the crown to its most outward position.
- 3) Set the watch to AM time by rotating the crown counterclockwise till the date indicator changes. *
- 4) Set the current time by rotating the crown counterclockwise. For AM, do not advance the hour hand past the 12 o'clock position - for PM, advance the hour hand past the 12 o'clock position once.
- 5) Push the crown in one click to the middle position.
- 6) Set the current date by rotating the crown counterclockwise until the correct value is displayed.
- 7) Push the crown in to its innermost position to commence timekeeping.
- 8) Return the crown protector to its latched position.

- To activate the chronograph, press the start / stop button above the crown, press again the pause / stop. Press the button below the crown to reset the chronograph.

* Setting the time to AM / PM accordingly ensures that the secondary indicators change at midnight rather than noon. If secondary indicators are changing in the afternoon, pull the crown to its most outward position and advance the hour hand one full rotation (12 hours), then reset date indicators as necessary.

** Although manual winding is not necessary, generating an initial power reserve and occasionally winding the movement manually will increase the duration in which the movement continues to operate when the watch is not worn.