

# Morphic M4 Series Timepieces

(MPH0401-MPH0406)

## Crown Protector:

- 1) Pull outwards on the upper edge of the protector to free it from its latching mechanism.
- 2) Relocate the protector to gain access to the crown.
- 3) Reposition the crown protector when use of crown is finished.

## Setting Instructions:

- 1) Relocate the crown protector.
- 2) Pull the crown out two clicks.
- 3) Set the current time by rotating the crown clockwise.
- 4) Push the crown in one click.
- 5) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 6) Push the crown in one click to commence timekeeping.
- 7) Reposition the crown protector.

**Note:** if the calendar indicator is changing in the afternoon advance the time 12 hours.

## Tachymeter Functions:

### Start / Stop / Reset

- 1) Press Button A to start the timer, press again to stop.
- 2) Press Button B to reset the timer / hands.

### Lap Tracking

- 1) Press Button A to start the timer.
- 2) Press Button B to pause the hands of the timers (tachymeter will continue running).
- 3) Press Button B to resume (timer hands will advance to current time).
- 4) To stop the timer press Button A (tachymeter and timer hands will stop), press again to resume.
- 5) To reset the timer press Button A to stop, then press Button B to reset.

Water Resistance Guidelines		
Rating	Submersible	Capacity of Resistance
No Marking	No	Splash/light contact only.
5ATM	No	Hand/dish washing.
10ATM	Yes	Low depth and short duration only.
20ATM	Yes	Short duration diving up to 5 meters.