

The Morphic M23 Series Timepiece

(MPH2301-MPH2314)



Setting Instructions:

- 1) Pull outwards on the center of the crown protector to free it from its latching mechanism.
- 2) Pull the crown out one click.
- 3) Set the current time by rotating the crown clockwise – reference the 24 hour sub dial to set to am / pm hours accordingly.
- 4) Push the crown in one click to commence timekeeping.
- 5) Reposition and secure the crown protector.

Note: The crown protector must be secured before wearing to ensure the rated water resistance is achieved.

Tachymeter Functions:

Start / Stop / Reset

- 1) Press Button A to start the timer, press again to stop.
- 2) Press Button B to reset the timer / hands.

Lap Tracking

- 1) Press Button A to start the timer.
- 2) Press Button B to pause the hands of the timers (tachymeter will continue running).
- 3) Press Button B to resume (timer hands will advance to current time).
- 4) To stop the timer press Button A (tachymeter and timer hands will stop), press again to resume.
- 5) To reset the timer press Button A to stop, then press Button B to reset.

Water Resistance Guidelines		
Rating	Submersible	Capacity of Resistance
No Marking	No	Splash/light contact only.
5ATM	No	Hand/dish washing.
10ATM	Yes	Low depth and short duration only.
20ATM	Yes	Short duration diving up to 5 meters.