

The Morphic *M37* Series Timepiece

(MPH3701-MPH3708)



Setting Instructions:

- 1) Pull the crown out two clicks.
- 2) Rotate the crown until the current time is displayed.
- 3) Push the crown in one click.
- 4) Rotate the crown until the date indicator displays the correct value.¹
- 5) Push the crown in one click to commence timekeeping.

Tachymeter Functions:

Start / Stop / Reset

- 1) Press *Button A* to start the timer, press again to stop.
- 2) Press *Button B* to reset the timer / hands.

Lap Tracking

- 1) Press *Button A* to start the timer.
- 2) Press *Button B* to pause the hands of the timers (tachymeter will continue running).
- 3) Press *Button B* to resume (timer hands will advance to current time).
- 4) To stop the timer press *Button A* (tachymeter and timer hands will stop), press again to resume.
- 5) To reset the timer press *Button A* to stop, then press *Button B* to reset.

Water Resistance Guidelines		
Rating	Submersible	Capacity of Resistance
No Marking	No	Splash/light contact only.
5ATM	No	Hand/dish washing.
10ATM	Yes	Low depth and short duration only.
20ATM	Yes	Short duration diving up to 5 meters.
25ATM+	Yes	Average depth and duration diving.

¹ If the date indicator is changing in the afternoon, advance the time 12 hours then reset the date indicator as required.