

The MOS *Casablanca* Timepiece

(CB101-CB105)



Setting Instructions:

- 1) Pull the crown out two clicks.
- 2) Rotate the crown clockwise to set the current time. Note: reference the 24 hour indicator to ensure the time is set to AM / PM hours accordingly.
- 3) Push the crown in one click to commence timekeeping.
- 4) Set calendar dial A by pressing button 1 until the correct value is displayed.
- 5) Set calendar dial B by pressing button 2 until the correct value is displayed.

Note: if the calendar indicators are cycling out of sync or changing in the afternoon, advance the time 12 hours (rotate the hour hand clockwise one full rotation).

Water Resistance Guidelines		
Rating	Submersible	Capacity of Resistance
No Marking	No	Splash/light contact only.
5ATM	No	Hand/dish washing.
10ATM	Yes	Low depth and short duration only.
20ATM	Yes	Short duration diving up to 5 meters.
25ATM+	Yes	Average depth and duration diving.