

The Reign *Gustaf* Timepiece

(RN1501 – RN1506)

Mechanical automatic watches harness the kinetic energy contained within the natural movement of your arm to generate the force required to operate. The watch will commence operation after a sufficient volume of initial power has been generated by handling / wearing or by manually winding the crown. Supplemental winding through wear or manual winding will ensure sustained functionality and increase the duration in which the watch will continue to operate when unworn.



Setting Instructions

- 1) Pull the crown out two clicks to its most outward position.
- 2) Set the current time by rotating the crown counterclockwise.
 - Reference the 24-hour sub dial to ensure AM/PM hours are set accordingly (0-12=AM, 12-24=PM).
- 3) Push the crown in one click to its middle position.
- 4) Set the current date by rotating the crown counterclockwise until the correct value is displayed.
- 5) Push the crown in to its rest / manual winding position to commence timekeeping.
- 6) Manually wind the mainspring by rotating the crown clockwise 10 - 20 times.
- 7) To set the current day of the week press Button A until the correct value is displayed.
- 8) To set the current month press Button B until the correct value is displayed.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary - a small pointed object may be used to actuate the recessed buttons.

Water Resistance Guidelines

10 ATM – Suitable for short duration and low depth bathing or swimming. **Note:** manipulation of the crown or buttons while in contact with water will negate the rated water resistance as water penetration may occur.