

# The Breed Raylan Timepiece

(BRD5801 - BRD5808)



## Setting Instructions:

- 1) Pull the crown out two clicks to its outermost position.
- 2) Rotate the crown clockwise until the date indicator advances one position.
- 3) Set the current time as follows:
  - for AM hours advance the hands directly to the current time,
  - for PM hours advance the hour hand one full rotation (12 hours) *once*, prior to setting the time.
- 4) Push the crown in one click to its middle position.
- 5) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 6) Push the crown in to its innermost position to commence timekeeping.

**Note:** Setting the time to AM / PM accordingly ensures that the date indicator changes at midnight rather than noon. If the date indicator is changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicator as necessary.

## Timer Functions:

### Start / Stop / Reset

- 1) Press Button A to start the timer, press again to stop.
- 2) Press Button B to reset the timer / hands.

### Lap Tracking

- 1) Press Button A to start the timer.
- 2) Press Button B to pause the hands of the timers (timer will continue running even though hands stop).
- 3) Press Button B to resume (timer hands will advance to current time).
- 4) To stop the timer press Button A, press again to resume.
- 5) To reset the timer press Button A to stop, then press Button B to reset.

### Timer Hand Adjustment

- 1) Pull the crown out to its outermost position.
- 2) Press Button A to adjust the timer *second* hand.
- 3) Press Button B to adjust the timer *minute* hand.
- 4) Once adjustment is completed, set the time / date as necessary then push the crown back in to its rest position to commence timekeeping.

**Note:** pressing Button A or B once will advance the associated timer hand by one increment, pressing and holding the button will advance the associated timer hand at an accelerated rate.

## Water Resistance Guidelines:

**5 ATM** – light contact and short duration resistance only. Not suitable for bathing, swimming, diving, or extended periods of contact. **Note:** manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance as water penetration may occur.