

The Crayo *Button* Timepiece

(CR0201 - CR0208)



Setting Instructions:

- 1) Pull the crown out two clicks to its outermost position.
- 2) To change the language of the day of the week indicator:
 - Rotate the crown counterclockwise until the day of the week indicator advances to the desired language,
 - Rotate the crown clockwise until the hour hand makes one full rotation,
 - Rotate the crown counterclockwise until the day of the week indicator displays the current day of the week.
- 3) Set the current time as follows:
 - for AM hours advance the hands directly to the current time,
 - for PM hours advance the hour hand one full rotation (12 hours) *once*, prior to setting the time.
- 4) Push the crown in one click to its middle position.
- 5) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 6) Push the crown in to its innermost position to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

Water Resistance Guidelines:

3 ATM – light contact / splash resistant only. Not suitable for bathing, swimming, diving, or extended periods of contact. **Note:** manipulation of the crown while the watch is in contact with water will negate the rated water resistance as water penetration may occur.