


The Morphic M34 and M42 Series Timepieces

(MPH3401-MPH3407 / MPH4201-MPH4206)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Rotate the crown clockwise until the day of the week indicator displays the correct value.
- 3) Set the current time by rotating the crown clockwise;
 - for AM hours **do not** advance the hour hand past the 12 o'clock position,
 - for PM hours advance the hour hand past the 12 o'clock position **once**.
- 4) Push the crown in one click.
- 5) Set the current date by rotating the crown counterclockwise until the correct value is displayed.
- 6) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicator changes at midnight rather than noon. If the date indicator is changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicator as necessary.

Water Resistance Guidelines

3 ATM – Splash / light contact only – not suitable for bathing or swimming. **Note:** Manipulation of the crown while the watch is in contact with water will negate the rated water resistance as water penetration may occur.