

The Reign *Toretto* Timepiece

(RN3501 – RN3507)

Mechanical automatic watches harness the kinetic energy contained within the natural movement of your arm to generate the force required to operate. The watch will commence operation after a sufficient volume of initial power has been generated by handling / wearing or by manually winding the crown. Supplemental winding through wear or manual winding will ensure sustained functionality and increase the duration in which the watch will continue to operate when unworn.

Setting Instructions

- 1) Free the crown protector from its latching mechanism and swing it out of the way.
- 2) Pull the crown out one click to the time setting position.
- 3) Set the current time by rotating the crown counterclockwise.
 - Reference the 24-hour sub dial to ensure AM/PM hours are set accordingly (0-12=AM, 12-24=PM).
- 4) Push the crown back in to the rest / manual winding position to commence timekeeping.
- 5) Manually wind the mainspring by rotating the crown clockwise 10 - 20 times.
- 6) Reposition and secure the crown protector.
- 7) Press Button A to set the day of the week sub dial.
- 8) Press Button B to set the date sub dial.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon, advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

Water Resistance Guidelines

5 ATM – Suitable for low depth and short duration water contact only, not suitable for bathing, swimming, or diving.

Note: manipulation of the crown or buttons while in contact with water will negate the rated water resistance as water penetration may occur.