

The Earth *Castillo* Timepiece

(EW5101 – EW5104)



Setting Instructions

- 1) Pull the crown out two clicks to its most outward position.
- 2) Set the current time by rotating the crown counterclockwise. Reference the 24-hour sub dial to ensure AM / PM hours are observed accordingly (0-12 = AM / 12-24 = PM).
- 3) Push the crown in one click to its middle position.
- 4) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 5) Push the crown in one click to its rest position to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures the date indicator changes at midnight rather than noon. If the date indicator is changing in the afternoon, advance the hour hand one full rotation (12 hours), then reset the date indicator as necessary.

Timer Functions

Press *Button A* to start / pause the timer.
Press *Button B* to reset the timer.

Water Resistance Guidelines

0ATM - Splash / light contact only, do not submerge. Not suitable for bathing, swimming, or diving.

Note: Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance as water penetration may occur.