

The Morphic M67 Series Timepiece

(MPH6701 – MPH6706)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Set the current time by rotating the crown clockwise. Reference the 24-hour sub dial to ensure AM / PM hours are observed accordingly (0-12 = AM / 12-24 = PM).
- 3) Push the crown in one click.
- 4) Set the current date by rotating the crown clockwise.
- 5) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures the date indicator changes at midnight rather than noon. If the date indicator is changing in the afternoon, advance the hour hand one full rotation (12 hours), then reset the date indicator as necessary.

Timer Functions

Button A – Start / Stop

Button B – Reset

Timer Seconds Sub Dial – Elapsed Time in Seconds

Timer Minutes Sub Dial – Elapsed Time in Minutes

Water Resistance Guidelines

5 ATM - may be submerged for short durations, in normal temperature fresh water only. Not suitable for bathing, swimming, watersports, or diving.

Note: Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance as water penetration may occur.