

The Morphic M57 and M61 Series Timepieces

(MPH5701 – MPH5707 / MPH6101 – MPH6106)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Set the current time by rotating the crown clockwise.
 - Reference the 24-hour sub dial to ensure AM / PM hours are observed accordingly (0-12 = AM / 12-24 = PM).
- 3) Push the crown in one click.
- 4) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 5) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicator changes at midnight rather than noon. If the date indicator has not changed to the current date by 6:00 AM, advance the hour hand one full rotation (12 hours), then reset the date indicator as necessary.

Chronograph Functions

Start / Stop / Reset

- 1) Press Button A to start the timer, press again to stop.
- 2) Press Button B to reset the timer / hands.

Lap Tracking

- 1) Press Button A to start the timer.
- 2) Press Button B to pause the hands of the sub dials (timer will continue running).
- 3) Press Button B to resume (sub dial hands will advance to current time).
- 4) To stop the timer press Button A, press again to resume.
- 5) To reset the timer press Button A to stop, then press Button B to reset.

Water Resistance Guidelines

5 ATM - may be submerged for short durations, in normal temperature fresh water only. Not suitable for bathing, swimming, watersports, or diving.

Note: Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance, as water penetration may occur.